


INSTRUCTION SHEET




Step 1.

Press wires into position (T568A/T568B)
Do not untwist conductor pairs more than 0.5".

MODULAR WIRING CONFIGURATION		
COLOR CODE	T568B	T568A
White-Blue	5	5
Blue	4	4
White-Orange	1	3
Orange	2	6
White-Green	3	1
Green	6	2
White-Brown	7	7
Brown	8	8


Step 2.

Terminate wires with a 110 punch down tool.
or Krone punch down tool.



110 punch down tool


OR



Krone punch down tool


Step 3.

Mount the wire management on the patch panel with 4 screws.



Module Replacement

Insert and rotate the slotted screwdriver as shown (2 places), take out the module from patch panel.



Insert the new module into patch panel until fixed.

