





INSTRUCTION SHEET



2 optional locations to screw grounding wire (included).





STEP 1:

Insert wires into IDC's according to the desired wiring configuration (T568B/T568A).
Terminate wires using punch down tool.
Make sure the tool is set to trim excess wire as shown.

STEP 2:

Snap keystone Jacks into patch panel.




STEP 3:


Recommended cable routing for terminated modules.
Terminate cables in the direction from A to B as indicated.

STEP 4:


Recommended cable routing for patch cords.




Concave Installation




Mount one side first then the other side.



STEP 1:
Pre-load screws onto the rack, and leave some space on the screws as shown.




STEP 2:
Mount the cable managements as shown, fit one side of concaves to the screws first, then adjust to mount the other side of concaves to the screws.




STEP 3:
Mount the angled patch panel in the same way in Step 2. Fasten all screws properly.

Screwdriver


Screw-hole Installation




Mount lower screws first then the upper screws.



STEP 1:
Mount angled patch panel and the lower cable management. Pre-load lower screws and leave some space on screws as shown.



STEP 2:
Between the gap of the rack and the angled patch panel, put in the upper cable managements as shown.



STEP 3:
Fasten all screws properly.

Screwdriver